




**INSPIRED BY
EFFICIENCY**



User manual

Interroll RollerDrive EC310

Manufacturer's address

Interroll Engineering GmbH
Hoeferhof 16
D-42929 Wermelskirchen
Tel. +49 2193 23 0
Fax. +49 2190 2022
www.interroll.com

Copyright

The copyright of this manual remains with Interroll Engineering GmbH. The operating instructions contain technical regulations and drawings which may not be reproduced partially or in full, transmitted by any means, utilized without permission for competitive purposes or disclosed to third parties.

Table of contents

Introduction	
Information about the operating instructions	2
Warnings in this manual	2
Further symbols	3
Safety	
General safety instructions	4
Intended use	4
Unintended use	4
Qualified persons	5
Dangers	5
Interfaces	6
Operating modes	6
Product information	
Components	7
Product Description	8
RollerDrive Label	9
Product identification	9
Technical specifications	10
Performance Data for RollerDrive EC310	10
DriveControls for the RollerDrive EC310	11
Speed settings	11
Motor plug	13
Dimensions of the Motor Shaft	14
Dimensions of idler cartridges	14
Arrangement of Round Belt Grooves	16
Conical RollerDrives	16
Transport and storage	
Transport	17
Storage	17
Assembly	
Warning information for assembly	18
Warning notices concerning the electrical installation	19
Installing the RollerDrive	20
Mounting tool	22
Electrical Installation	22
Initial startup and operation	
Commissioning	23
Operation	23
Procedure in case of accident or malfunction	23
Maintenance and cleaning	
Warnings concerning maintenance and cleaning	24
Maintenance	24
Cleaning	24
Troubleshooting	
Troubleshooting	25
Abandonment and disposal	
Abandonment	26
Disposal	26
Appendix	
Accessories	27
Installation Declaration	28

Introduction

Information about the operating instructions

Contents

This manual contains important advice, notes and information about the RollerDrive EC310 in all phases of its lifecycle:

- Transport, assembly and start-up
- Safe operation, maintenance and troubleshooting, disposal
- Accessories

Validity of the manual

The manual describes the RollerDrive EC310 as it is delivered by Interroll.

In addition to this manual, special contractual agreements and technical documents apply to special versions.

The manual is part of the product

- For trouble-free, safe operation and warranty claims, read the manual and follow the instructions before handling the RollerDrive EC310.
- Keep the manual near to the RollerDrive EC310.
- Pass the manual on to any subsequent operator or occupant of the RollerDrive EC310.
- Interroll does not accept any liability for malfunctions or defects due to non-observance of this manual.
- If you have any questions after reading the operation manual, feel free to contact our customer service. See the last page for your local contact.

Warnings in this manual


The warnings in this document refer to risks which may arise while using the RollerDrive EC310. For relevant warnings, see "Safety", page 4 and the warnings at the beginning of each chapter.


There are three categories of danger. The following signal words are used in the document as required:

- Danger
- Warning
- Caution

Signal word	Meaning
Danger	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
Warning	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
Caution	Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury.

Structure of warnings




DANGER

Nature and source of the hazard
Possible consequence of non-observance

- Information about how to avoid the hazard.

Introduction

Further symbols

NOTICE

This symbol identifies possible material damage.
➤ Information about how to avoid damage.



This symbol displays safety instructions.



This symbol marks useful and important information.

➤ This symbol marks the steps that have to be carried out.

Safety

General safety instructions

The RollerDrive EC310 is designed according to the technical state of the art and is reliable in operation, once distributed. However, risks may still arise.

- Risks of physical injury to the user or bystanders.
- Adverse effects of the RollerDrive and other material.



Disregarding the warnings in this manual may lead to serious injury.

- Always read the entire operating and safety instructions before starting to work with the RollerDrive and follow the information contained herein in full.
- Only instructed and qualified persons may work with the RollerDrive.
- Always keep this user manual at hand when working on the RollerDrive so that you can consult it quickly if required.
- Always comply with relevant national safety regulations.
- If you have any questions after reading this user manual, feel free to contact our customer service. See the last page for contact information.

Intended use

The RollerDrive EC310 may only be used for industrial applications and in an industrial environment to convey goods such as parts, cartons, totes or boxes. It must be integrated in a conveyor module or a conveying system. Any other use is not permitted.

Any changes that affect the safety of the product are not allowed.

The RollerDrive EC310 may only be used within the given operation limits.

Unintended use

The RollerDrive EC310 may not be used to transport persons, bulk cargo or small parts.

The RollerDrive is not intended for use under impact or shock loads.

Applications not according to the intended use of the RollerDrive EC310 require approval from Interroll.

Safety

Qualified persons

Qualified persons are persons who read and understand the manual and, taking national regulations into account, can competently execute incidental work.

Only instructed and qualified persons may work with the RollerDrive, taking the following into account:

- the relevant manuals and diagrams,
- the warning and safety instructions in this manual,
- the system specific regulations and requirements,
- national or local regulations and requirements for safety and accident prevention.

Dangers



The following list provides information about the various types of danger or damage that may occur while working with the RollerDrive EC310.

- | | |
|--------------------------------|---|
| Bodily injury | <ul style="list-style-type: none">➤ Maintenance or repair work must only be performed by authorized and qualified persons in accordance with the applicable regulations.➤ Before turning on the RollerDrive, ensure that no unauthorized persons are near the conveyor. |
| Electricity | <ul style="list-style-type: none">➤ Only perform installation and maintenance work after you have switched off the power. Ensure that the RollerDrive cannot be turned on accidentally. |
| Rotating parts | <ul style="list-style-type: none">➤ Keep your fingers and hair away from moving parts.➤ If you have long hair, always wear a hair net.➤ Never wear loose clothing.➤ Never wear jewelry, such as necklaces or bracelets.➤ Wear safety shoes. |
| Heat | <ul style="list-style-type: none">➤ Do not touch the RollerDrive during operation. With applications with high switching cycles, the temperature of the tube can reach up to 60 °C (140 °F). |
| Working environment | <ul style="list-style-type: none">➤ Do not use the RollerDrive in explosive atmospheres.➤ Remove equipment or material which is not required from the workspace.➤ Wear safety shoes.➤ Regulate and monitor careful placement of the goods on the conveyor. |
| Faults during operation | <ul style="list-style-type: none">➤ Regularly check the RollerDrive for visible damage.➤ In case of fumes, unusual noise or blocked or damaged goods, stop the RollerDrive at once and ensure that the RollerDrive cannot be started accidentally.➤ Contact qualified personnel immediately to find the source of the fault.➤ Do not step on the RollerDrive during operation. |
| Maintenance | <ul style="list-style-type: none">➤ As the product is maintenance free, you only need to check regularly for visible damages, unusual noise and that the screws and nuts are still tightened.➤ Do not open the RollerDrive. |
| Accidental start-up | <ul style="list-style-type: none">➤ Make sure that the RollerDrive cannot start up accidentally, particularly during assembly, maintenance work and in the event of a fault. |

Safety

Interfaces

By assembling the RollerDrive in a conveyor module, potential hazards may occur. These are not described in this manual and have to be analyzed during the design, installation, and startup of the conveyor module.

- After assembling the RollerDrive in a conveyor module, check the whole system for any new potential dangerous condition prior to turning on the conveyor.


Operating modes

Normal mode	Operation of the installed device at the end customer's as a component in a conveyor in a complete system.
Special mode	All operating modes which are required to guarantee and maintain safe and normal operation.

Special operating mode	Explanation	Comment
Transport/Storage	Loading and unloading, transport and storage	-
Assembly/Initial start-up	Installation at the end customer's and performing the test run	When de-energized
Cleaning	External cleaning	When de-energized
Maintenance/Repairs	Maintenance and inspection tasks	When de-energized
Troubleshooting	Troubleshooting in the event of a fault	When de-energized
Fault elimination	Eliminating the fault	When de-energized
Shut-down	Dismantling from the conveyor	When de-energized
Disposal	Disposal of RollerDrive and packaging	-

Product information

Components



Product information

Product Description

The RollerDrive EC310 is an electronically commutated drive roller. The motor electronics, motors and gears are installed in the RollerDrive . It has nine gear stages and can be operated at a constant conveying speed.

Overload protection device

There are several overload protection systems.

- **Stall timing device:** If the RollerDrive is stalled while there is a run command, the motor tries to restart ten times every three seconds for one second. If the stall persists after these ten attempts, a failure signal is set and the RollerDrive tries to restart with a 60:1 cycle (restart for one second every 60 seconds) until the stall is eliminated. The RollerDrive will not be damaged if the system operates in a stall time device mode for a long period of time. If the RollerDrive is running at the selected speed again or the run command is withdrawn, the failure signal will be cancelled.
- **Slow running:** If there is a speed deviation of +/- 20% from the chosen value for more than 10 seconds, the motor will be switched off and the failure signal will be set. The RollerDrive will try to start again after 60 seconds. If the RollerDrive is running at the selected speed again or the run command is withdrawn, the failure signal will be cancelled.
- **Temperature monitoring:** The temperature of the motor and electronic assemblies is monitored.

If used appropriately, the roller can be installed in the conveyor with the required controls and then operated maintenance-free throughout the service life of the product.

Holding brake (Zero Motion Hold)

The RollerDrive EC310 is fitted with an electronic holding brake that allows it to be used on conveyors on a gradient or incline. The motor's rotor is held in position if no travel signal is pending. In the event of failure of the supply voltage, the holding brake becomes ineffective as it is not a mechanical brake.


Energy feedback

The RollerDrive EC310 feeds energy back when the goods being conveyed brake. This results in the motor heating up less in operation and improves the energy efficiency of the system. Interroll DriveControls are fitted with a switch that prevents the voltage rising above 28 V in the supply voltage. When installing the system, ensure that the power units are capable of feedback.

Product information

RollerDrive Label

The information on the RollerDrive label is used to identify the RollerDrive. This is necessary in order to use the RollerDrive as intended.



The diagram shows a circular label with the following information and callouts:

- 1: Manufacturer (INTERROLL)
- 2: Date of production (03/10)
- 3: Gear ratio (16:1)
- 4: Performance (37 W)
- 5: Rated voltage (24 VDC)
- 6: Speed range (0,05 – 0,98 m/s)
- 7: Type of RollerDrive (EC 310)
- 8: Serial number (123456789)

Label

① Manufacturer	⑤ Rated voltage
② Date of production	⑥ Speed range
③ Gear ratio	⑦ Type of RollerDrive
④ Performance	⑧ Serial number

Product identification

The following information is needed to identify a RollerDrive. You can enter the values of your RollerDrive in the last column.

Information	Possible value	Own value
RollerDrive type plate	Motor type Gear ratio Serial number	
Tube diameter	50 mm or 1.9 in	
Tube material	Zinc-plated, aluminum or stainless steel (with or without sleeves)	
Roller installation lengths	EL/BF	
Roller transmission	Torque transmission	
Idler shaft	Spring loaded or female threaded shaft pin (see "Dimensions of idler carriages", page 14)	

Product information

Technical specifications

Rated voltage	24 VDC
Voltage range	18 to 28 VDC
Idle current	0.4 A
Rated current	2 A
Maximum peak current	5 A
Rated power	32 W
Maximum ripple from power supply	3 %
Maximum number of starts/stops per minute	30
Maximum noise emission (mounted)	55 dB(A) ¹⁾
Protection classification	IP54 or IP66
Ambient temperature in operation	0 °C to 40 °C (32 °F to 104 °F)
Ambient temperature during transport and storage	-30 °C to +75 °C (-22 °F to +167 °F)
Air humidity	5 to 85 %
Installation height above sea level	max. 1000 m (max. 3300 ft)



Data applies to an ambient temperature of 20 °C (68 °F).

¹⁾ Value can vary according to installation conditions, profile shapes and the resonance behavior of the system.

Performance Data for RollerDrive EC310

Gear ratio	Speed range m/s	Nominal torque Nm	Starting torque Nm	Holding torque Nm
9:1	0.09 to 1.75	0.45	1.10	0.36
12:1	0.07 to 1.31	0.61	1.46	0.48
16:1	0.05 to 0.98	0.81	1.95	0.64
20:1	0.04 to 0.78	1.01	2.44	0.80
24:1	0.03 to 0.65	1.21	2.92	0.96
36:1	0.02 to 0.44	1.82	4.38	1.44
48:1	0.02 to 0.33	2.42	5.85	1.92
64:1	0.01 to 0.25	3.23	7.80	2.56
96:1	0.01 to 0.16	4.84	11.69	3.84

Product information

DriveControls for the RollerDrive EC310

Interroll recommends using the RollerDrive EC310 in combination with the corresponding Interroll DriveControl 20 or 54.



For more detailed information on the DriveControl, please refer to the corresponding operating manual, relevant catalogues or publications at www.interroll.com.

Speed settings

If you do not use the recommended DriveControl (see "DriveControls for the RollerDrive EC310", page 11), you may change the speed of the RollerDrive EC310 by altering the voltage on pin 5 of the motor plug.

Speed setting on the DriveControl

DIP switch setting on the DriveControl				Speed at gear ratio								
A	B	C	D	m/s								
				9:1	12:1	16:1	20:1	24:1	36:1	48:1	64:1	96:1
on	on	on	on	1.75	1.31	0.98	0.78	0.65	0.44	0.33	0.25	0.16
on	on	on	off	1.63	1.22	0.92	0.73	0.61	0.41	0.31	0.23	0.15
on	on	off	on	1.51	1.13	0.85	0.68	0.57	0.38	0.28	0.21	0.14
on	on	off	off	1.39	1.04	0.78	0.62	0.52	0.35	0.26	0.20	0.13
on	off	on	on	1.27	0.95	0.72	0.57	0.48	0.32	0.24	0.18	0.12
on	off	on	off	1.15	0.86	0.65	0.52	0.43	0.29	0.22	0.16	0.11
on	off	off	on	1.03	0.78	0.58	0.47	0.39	0.26	0.19	0.15	0.10
on	off	off	off	0.92	0.69	0.52	0.41	0.34	0.23	0.17	0.13	0.09
off	on	on	on	0.80	0.60	0.45	0.36	0.30	0.20	0.15	0.11	0.07
off	on	on	off	0.68	0.51	0.38	0.31	0.25	0.17	0.13	0.10	0.06
off	on	off	on	0.56	0.42	0.32	0.25	0.21	0.14	0.11	0.08	0.05
off	on	off	off	0.44	0.33	0.25	0.19	0.17	0.11	0.08	0.06	0.04
off	off	on	on	0.32	0.24	0.18	0.15	0.12	0.08	0.06	0.05	0.03
off	off	on	off	0.21	0.15	0.12	0.09	0.08	0.05	0.04	0.03	0.02
off	off	off	on	0.09	0.07	0.05	0.04	0.03	0.02	0.02	0.01	0.01
off	off	off	off	Stop or in accordance with the signals on the Speed A-C ports								

Product information


External speed setting via digital inputs

Speed input on the DriveControl *			Speed at gear ratio								
			m/s								
A	B	C	9:1	12:1	16:1	20:1	24:1	36:1	48:1	64:1	96:1
H	H	H	1.75	1.31	0.98	0.78	0.65	0.44	0.33	0.25	0.16
H	H	L	1.47	1.10	0.83	0.66	0.55	0.37	0.28	0.21	0.14
H	L	H	1.19	0.89	0.67	0.53	0.45	0.30	0.22	0.17	0.11
H	L	L	0.92	0.69	0.52	0.41	0.34	0.23	0.17	0.13	0.09
L	H	H	0.64	0.48	0.36	0.29	0.24	0.16	0.12	0.09	0.06
L	H	L	0.36	0.27	0.20	0.17	0.14	0.09	0.07	0.05	0.03
L	L	H	0.09	0.07	0.05	0.04	0.03	0.02	0.02	0.01	0.01
L	L	L	0	0	0	0	0	0	0	0	0

* H = logically active; L = logically inactive

Product information

Motor plug



Pin	Color	Function	Value
1	brown	Power supply input (+)	Rated voltage: 24 VDC Voltage range: 18 to 28 VDC
2	white	Direction of rotation, seen from the cable end of the RollerDrive	$U < 4 \text{ V}$ = counter clockwise $U > 7 \text{ V}$ = clockwise
3	blue	Earth for power supply and signal (-)	Ground
4	black	Fault output	Open Collector $U_{\text{cesat}} = 0.5 \text{ V}$ for $I_{\text{c}} = 5 \text{ mA}$ $U_{\text{max}} = 30 \text{ V}$ $I_{\text{cmax}} = 5 \text{ mA}$ Error: Signal low No fault: Signal high
5	gray	Analogue speed/start signal	see table below

Analogue speed/start signal (Pin 5)

Voltage range	0 to 24 VDC
Stop (braked state)	0 to 2.3 VDC
Speed	2,3 VDC to 10 VDC (Incline rate above 2.3 VDC: 740 rpm (motor revolutions) linear between 2.3 and 10 VDC)
Max. speed	10 VDC to 24 VDC

The conveyor speed is calculated from the gear ratio and the nominal value.
(also see "Speed settings", page 11)



In case the RollerDrive is not directly connected to the corresponding DriveControl or the Interroll extension cable, connect the motor plug using a Conec M8 snap-in coupling.

NOTICE


Pins 1 and 3 are not protected against incorrect polarity connection.

Damage to the motor.

➤ Ensure the correct polarity.

Product information

Dimensions of the Motor Shaft





Dimensions of idler cartridges


11 mm (0.44 in) hex,
spring-loaded shaft

Female threaded M8 (FTM8) shaft pin



Straight





Straight IP66



Round belt head



PolyVee head




Product information

11 mm (0.44 in) hex,
spring-loaded shaft


Female threaded M8 (FTM8) shaft pin

PolyVee head IP66




Toothed belt head

Poly-Chain GT; 8 mm pitch; 18 teeth



Sprocket head

11 mm (0.44 in) hex shaft; 3/8 in pitch;
20 teeth




BF/EL = Between Frames / Installation Length


Product information

Arrangement of Round Belt Grooves

**IGM8 female thread shaft pin,
single bearing**



**Spring-loaded hex, double
bearing**



Other tube groove arrangements are possible.



Conical RollerDrives

For conical RollerDrives there must be an 1.8° angle compensation on both end to avoid bending forces on the RollerDrive.

Transport and storage



Transport

- Every RollerDrive has end-protectors to cover its ends.

	 CAUTION
There is a risk of injury if transported incorrectly	
<ul style="list-style-type: none">➤ Only qualified and authorized persons should transport the product.➤ Follow the instructions below.	

- Do not stack pallets.
- Do not stack more than four cardboard boxes on top of each other.
- Check that the RollerDrives are correctly fixed prior to transport.
- Avoid serious impacts during transport.
- Check every RollerDrive for visible damage after transport.
- In the event of damage, take photos of the damaged parts.
- Report any damage caused by transport immediately to the transport company and Interroll to retain the right to claim for compensation.
- Do not expose the RollerDrives to serious fluctuations in temperature as this could lead to condensation.

Storage

	 CAUTION
Risk of injury due to improper storage	
<ul style="list-style-type: none">➤ Do not stack pallets.➤ Do not stack more than four cardboard boxes on top of each other.	

- Check each RollerDrive for damage after storage.

Assembly

Warning information for assembly



CAUTION

Rotating parts

Risk of pinched fingers

- Do not insert fingers between the RollerDrive and the round belt, PolyVee belt or roller chain.
- Install a protection device (such as a guard plate) to prevent fingers from getting trapped in the round belt, PolyVee belt or roller chain.
- Install an appropriate warning on the conveyor.

NOTICE

Risk of damage leading to failure or shortened life expectancy of the RollerDrive

- Follow the instructions below.

- Do not drop or mishandle the RollerDrive to avoid internal damage.
- Check each RollerDrive visually for damage before assembly.
- In order to prevent damage to the internal connections, do not hold, carry or secure the RollerDrive by the motor cable.
- Do not force the RollerDrive when inserting it into the conveyor frame. It should fit easily into the holes in the frame.
- Ensure that the proper tightening torque is applied to the RollerDrive hex nut to prevent the shaft spinning in the frame and the wires twisting (see "*Securing the RollerDrive in the conveyor frame*", page 22).
- Do not twist the motor cable.

Assembly

Warning notices concerning the electrical installation

NOTICE

Risk of damage to the motor and/or RollerDrive cables

➤ Observe the following safety information.

- All electrical work should only be performed by qualified and authorized persons.
- Disconnect the power supply before installing, removing or rewiring the RollerDrive.
- Do not apply AC current to the RollerDrive or DriveControl device at any time, as this will cause irreparable damage.
- Do not apply too much tension or load to the motor plug. Bending the cable and forcing the star washer over the cable can cause damage to the cable's insulation, which could result in failure of the RollerDrive.
- Ensure that the RollerDrive, the DriveControl and the 24 VDC power source are properly earthed through the conveyor frame or supporting structure in which the RollerDrive and the DriveControl are installed. Incorrect earthing can result in the build-up of static charge, causing the motor or DriveControl to malfunction or fail prematurely.
- Do not bend the motor cable at the motor shaft. Leave a minimum of 12 mm (0.5 in) of excess cable for stress relief.
- Give the start signal with a delay of at least 500 ms after switching on the power supply. Switching on the power supply and the start signal at the same time results in peak currents in excess of 5 A and damages the RollerDrive.

Assembly

Inserting the motor shaft




Installing the RollerDrive

- Remove any packaging and transport safety devices from the RollerDrive.
- When installing the RollerDrive, particularly in coated profiles, it must be ensured that the fastening nuts and any star washers or torque safety devices used establish electrical contact with the profile to enable ground contact.
- Insert the motor cable and motor shaft into the hexagonal hole measuring at least 11.2 mm (0.44 in) or the round hole measuring at least 12.2 mm (0.48 in) in the conveyor frame.


NOTICE

Internal damage to the RollerDrive due to improper handling

- Do not yet fit the retaining nut.
- Do not bend the motor cable at the motor shaft. Leave a minimum of 12 mm (0.5 in) of excess cable for stress relief.



- Fit one or two round belts, size 4 mm, max. 5 mm (3/16 in) or PolyVee belts (if used).




Assembly

Inserting the idler shaft


The type of axis dictates how the idler shaft is inserted in the conveyor frame. The spring-loaded shaft is simplest to install.

Inserting the spring-loaded hexagonal shaft

- Push the spring-loaded shaft inwards and align the shaft with the hole in the conveyor frame.




- Release the spring-loaded hexagonal shaft and allow it to pop into the hole in the frame.



Inserting the female thread shaft pin

- Place a split washer onto a M8 x 20 bolt.
- Align the RollerDrive with the hole in the conveyor frame and insert the M8 bolt and split washer into the shaft. Use a wrench to prevent the shaft pin from turning (width across flats AF 13 mm or AF 19 mm, depending on the shaft pin type, see *"Arrangement of Round Belt Grooves"*, page 16).



- Use a torque wrench to tighten the bolt with 20 Nm (177 in/lbf) until the split washer is completely compressed.

Assembly


Securing the RollerDrive in the conveyor frame

There is a nut on the shaft next to the tube. This inner nut has been preassembled and secured in the correct position.



Do not twist the inner nut.

- Use a flat wrench AF 17 mm to prevent the inner nut from turning. Use a wrench AF 36 mm with the IP66 configuration.
- Slip the nut included in the scope of supply over the motor cable and screw onto the threaded motor shaft.




- Use a torque wrench to tighten this nut with 70 Nm (619 in/lbf) while ensuring that the inner nut is not rotating.




An angular compensation on the motor end is needed to prevent bending forces on conical RollerDrives.

Mounting tool

For mounting the PolyVee belt, you may want to build a mounting tool as shown in the figure below.



- Place the mounting tool between two rollers to reduce the gap between the adjacent rollers.



Dimensions of the mounting tool depend on the roller pitch and the roller tube diameter.

Electrical Installation

- If the recommended DriveControl (see "*DriveControls for the RollerDrive EC310*", page 11) is used, connect the motor plug to the DriveControl.
- If the DriveControl is not used, connect your control to the motor plug (refer to see "*Motor plug*", page 13 for the pin assignment)

Initial startup and operation

Commissioning


Pre-commissioning checks

- Ensure that no objects are in contact with rotating or moving parts.
- Ensure that all bolts are tightened according to the specifications.
- Ensure that there are no additional areas of danger caused by interfaces to other components.
- Ensure that the wiring is in accordance with the specification and legal directives.
- Check all protection devices.
- Ensure that no personnel stand in hazardous areas near the conveyor.



For information on commissioning, refer to the DriveControl manual or the manual for your motor control.

Operation

	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">CAUTION</div> <p>Rotating parts and accidental start-up Risk of crushed fingers</p> <ul style="list-style-type: none"> ➤ Do not insert fingers between the RollerDrive and the round belt, PolyVee belt or roller chain. ➤ Do not remove the protection device. ➤ Keep fingers, hair and loose clothing away from the RollerDrive.
---	--

NOTICE	<p>Damage to the motor or the control due to induction</p> <ul style="list-style-type: none"> ➤ Do not push items along the roller conveyor by hand. ➤ Do not spin the RollerDrive manually.
---------------	---

Pre-commissioning checks

- Check the RollerDrive for visible damage.
- Check all protection devices.
- Ensure that no personnel stand in hazardous areas near the conveyor.
- Clearly specify and monitor the way goods are placed on the conveyor.
- Ensure that the RollerDrive is not blocked.



Ambient conditions during operation see *"Technical specifications"*, page 10

Procedure in case of accident or malfunction

- Stop the conveyor at once and ensure that it cannot be started accidentally.
- In case of an accident: Provide first aid and call for emergency assistance.
- Inform responsible persons.
- Have the malfunction repaired by qualified persons.
- Start the conveyor only after this has been approved by qualified persons.

Maintenance and cleaning

Warnings concerning maintenance and cleaning



CAUTION

Risk of injury due to improper handling or accidental motor starts

- Maintenance work and cleaning may only be executed by qualified and authorized persons.
- Only perform maintenance work after switching off the power. Ensure that the RollerDrive cannot be turned on accidentally.
- Set up signs indicating maintenance work.

Maintenance

Checking the RollerDrive

If the RollerDrive is not secured as specified in the installation instructions (see "Assembly", page 18), it may rotate in the hole in the conveyor frame. This will result in the roller leads becoming twisted and eventually severed.

- Monthly check the RollerDrive for visible damage.
- Annually ensure that the roller shaft is secured properly in the conveyor frame.

Replacing a RollerDrive

If a RollerDrive is damaged or broken down, it has to be replaced.

- Install a new RollerDrive (see "Abandonment", page 26 and see "Installing the RollerDrive", page 20).


Cleaning

Increased surface friction reduces the roller speed since more power is used to overcome the resistance. Therefore, in a dirty environment, periodic cleaning will ensure good contact with the goods and reduce friction.

- Remove foreign materials and dirt with a simple cleaning brush (not a wire brush) by brushing gently.
- Remove smaller amounts of dirt with a damp cloth. When doing this, make sure that wetting of the RollerDrive is no more than slightly damp.
- Do not use sharp-edged tools to clean the roller.

Troubleshooting

Troubleshooting

	<p>CAUTION</p> <p>Risk of injuries due to incorrect handling</p> <ul style="list-style-type: none"> ➤ Troubleshooting may only be done by qualified and authorized persons. ➤ Only perform troubleshooting after switching off the power. ➤ Ensure that the RollerDrive cannot be turned on accidentally.
---	--

Symptom	Possible cause	Help
RollerDrive does not run	No power supply	Check 24 VDC power supply.
	Plug not connected properly	Check cable connection.
RollerDrive is rotating in the wrong direction or at the wrong speed	Wrong DriveControl settings on the speed and rotational direction Dip switches	Change setting on DriveControl.
	Wrong voltage at speed setting pin (if the RollerDrive is not operated with the recommended Interroll DriveControl)	Check the voltage of the speed setting pins on the motor plug.
Abnormal noise coming from the RollerDrive	Motor or gearbox is damaged	Replace the RollerDrive.
Interrupted RollerDrive operation	Damaged motor cable	Check motor cable for damage. If the motor cable is damaged, replace the RollerDrive.
	RollerDrive overloaded	<i>see "Overload protection device", page 8</i>

Abandonment and disposal

Abandonment



CAUTION

Risk of injury due to improper handling

- Abandonment may only be executed by qualified and authorized persons.
- Only abandon the RollerDrive after switching off the power. Ensure that the RollerDrive cannot be turned on accidentally.

- Disconnect the motor cable from the control.
- Unscrew the outer nut at the threaded motor shaft.
- If the RollerDrive has a spring-loaded idler shaft, push the idler shaft inwards.
- If the RollerDrive has a FTM8 idler shaft, unscrew the bolt at the idler shaft.
- Extract the RollerDrive from the conveyor frame.

Disposal

The operator is responsible for the proper disposal of the RollerDrive. In doing so, industry-specific and local provisions must be observed for the disposal of the RollerDrive and its packaging.

Appendix

Accessories

Belt

Part	Properties
Toothed belt	<ul style="list-style-type: none"> Gates Poly-Chain GT or similar: Pitch 8 mm (0.31 in) Toothed belt width: 11.2 mm (0.44 in) Hub with 18 teeth
Round belt	<ul style="list-style-type: none"> Belts with 4 mm (0.16 in) and max. 5 mm (0.20 in) diameter
PolyVee belt	<ul style="list-style-type: none"> Drive head with 9 grooves for flexible V-ribbed belts PJ form, ISO 9981, DIN 7867 Pitch 2.34 mm (0.09 mm) Belts with a max. of 4 ribs

Controls

Part	Part no.
DriveControl 20	S-1001415
DriveControl 54	S-1001416
ZoneControl	S-1004023
SegmentControl	S-1004024
ComControl	S-1004025

Connection accessories

Part	Properties	Part no.
Connecting cable RollerDrive EC310 on DriveControl	Length: 2000 mm	S-1004033

Appendix

Installation Declaration

in accordance with the EC Machinery Directive 2006/42/EC, Appendix II B

The manufacturer:

Interroll Engineering GmbH
Hoeferhof 16
D - 42929 Wermelskirchen
Germany

hereby declares with sole responsibility that the product range

- RollerDrive EC310

is not a ready-to-use machine as defined by the EC Machinery Directive and, therefore, does not fully comply with the requirements of this directive. The commissioning of these conveyor modules is not permitted until conformity of the entire machine/system in which they are installed has been declared in compliance with the EC Machinery Directive.

The health and safety requirements as stated in Appendix I have been applied. The special technical documents as stated in Appendix VII B have been compiled and will be sent to the responsible authority if necessary.

Person authorized to compile the technical documents: Georg Malina, Interroll Engineering GmbH, Hoeferhof 16, D - 42929 Wermelskirchen

Applied EC directives:

- Machinery Directive 2006/42/EC
- EMC Directive 2004/108/EC
- RoHS Directive 2002/95/EC

Applied harmonized standards:

- EN ISO 12100 Parts 1 and 2 "Safety of machinery - Basic concepts, general principles for design" - Part 1: "Basic terminology, methodology" - Part 2: "Technical principles"

Wermelskirchen, 31st March 2010

Armin Lindholm
(Managing Director)

(This declaration can be obtained at www.interroll.com, if needed.)



